




Reset Switch to make printer recognise the cartridges







Ciss with original cartridge. The ciss uses the Original cartridge signal to fool the printer into thinking all the cartridges are original.

## The following pictures show how to lay the ciss tubes with various printers















